




# DHCP & WIRESHARK EXPERIMENT




Acknowledgement: Derived for the course by Ibrahim Aljubayri from exercises in Kurose and Ross text (See references provided in the first lecture)

## DHCP EXPERIMENT

- In order to observe DHCP in action, we'll perform several DHCP-related commands and capture the DHCP messages exchanged as a result of executing these commands by using Wireshark.



- We start by opening the Windows Command Prompt application.
- Go to Run → cmd



## ○ Type in “ipconfig”

- This command will show you your current IP address. You got it dynamically as soon as you laptop discovered the DHCP server.

```
Microsoft Windows [Version 6.3.9600]
(c) 2013 Microsoft Corporation. All rights reserved.

C:\Users\ibrahim>ipconfig

Windows IP Configuration

Wireless LAN adapter Local Area Connection* 2:
  Media State . . . . . : Media disconnected
  Connection-specific DNS Suffix . . . . . :


Wireless LAN adapter Wi-Fi:
  Connection-specific DNS Suffix . . . . . : stevens-tech.edu
  Link-local IPv6 Address . . . . . : fe80::55b7:5b68:82cd:87e0%4
  IPv4 Address . . . . . : 155.246.169.219
  Subnet Mask . . . . . : 255.255.255.0
  Default Gateway . . . . . : 155.246.169.1

Ethernet adapter Ethernet:
  Media State . . . . . : Media disconnected
  Connection-specific DNS Suffix . . . . . :
```

Dynamic IP address

## ○ Type in “ipconfig /release”

- This command releases your current IP address. So, you have no IP address



```
C:\Windows\system32\cmd.exe
Microsoft Windows [Version 6.1.7601]
Copyright <c> 2009 Microsoft Corporation. All rights reserved.

C:\Users\User>ipconfig/release

Windows IP Configuration

Ethernet adapter Local Area Connection 4:
  Connection-specific DNS Suffix . . .
  Link-local IPv6 Address . . . . . fe80::446a:b4ba:d296:ea06%15
  Default Gateway . . . . . .


Tunnel adapter isatap.stevens-tech.edu:
  Media State . . . . . Media disconnected
  Connection-specific DNS Suffix . . .

Tunnel adapter 6T04 Adapter:
  Media State . . . . . Media disconnected
  Connection-specific DNS Suffix . . .

Tunnel adapter Teredo Tunneling Pseudo-Interface:
  Media State . . . . . Media disconnected
  Connection-specific DNS Suffix . . .
```

No IP address

- Now start up the Wireshark packet sniffer, and begin Wireshark packet capture.




- Now go back to the Windows Command Prompt and type “ipconfig /renew”.
  - This instructs your host to obtain a network configuration, including a new IP address.

Network configuration

C:\> C:\Windows\system32\cmd.exe  
Microsoft Windows [Version 6.1.7601]  
Copyright (c) 2009 Microsoft Corporation. All rights reserved.  
C:\>Users\User>ipconfig/renew  
Windows IP Configuration  
  
Ethernet adapter Local Area Connection 4:  
Connection-specific DNS Suffix . : lib.stevens-tech.edu  
Link-local IPv6 Address . . . . . : fe80::446a:b4ba:d296:ea06%15  
IPv4 Address . . . . . : 155.246.184.41  
Subnet Mask . . . . . : 255.255.255.0  
Default Gateway . . . . . : 155.246.184.1  
  
Tunnel adapter isatap.{674D25A8-1DC1-4002-9FF2-5088C6A0E3AF}:  
Media State . . . . . : Media disconnected  
Connection-specific DNS Suffix . . . . . :  
  
Tunnel adapter 6TO4 Adapter:  
Connection-specific DNS Suffix . . . . . : lib.stevens-tech.edu  
IPv6 Address . . . . . : 2002:9bf6:b829::9bf6:b829  
Default Gateway . . . . . :  
  
Tunnel adapter Teredo Tunneling Pseudo-Interface:  
Media State . . . . . : Media disconnected  
Connection-specific DNS Suffix . . . . . :  
  
C:\>Users\User>

new IP address  
155.246.184.41

- Enter the command “ipconfig/release” to release the previously-allocated IP address to your computer.
- Finally, enter “ipconfig /renew” to again be allocated an IP address for your computer.
- Now go back to Wireshark and stop the packet capturing.



- Now let's take a look at the resulting WireShark window.
- Hint:** To see only the DHCP packets, enter into the filter field “bootp”

Capturing from Wi-Fi [Wireshark 1.10.5 (SVN Rev 54262 from /trunk-1.10)]

File Edit View Go Capture Analyze Statistics Telephony Tools Internals Help

Filter: bootp Expression... Clear Apply Save

No.	Time	Source	Destination	Protocol	Length	Info
44	7.468187000	155.246.169.219	155.246.151.135	DHCP	342	DHCP Release - Transaction ID 0x65fb07ac
152	13.147013000	0.0.0.0	255.255.255.255	DHCP	342	DHCP Discover - Transaction ID 0x2fa3c7f1
159	13.558377000	155.246.151.135	255.255.255.255	DHCP	354	DHCP Offer - Transaction ID 0x2fa3c7f1
160	13.558797000	0.0.0.0	255.255.255.255	DHCP	353	DHCP Request - Transaction ID 0x2fa3c7f1
161	13.566782000	155.246.151.135	255.255.255.255	DHCP	354	DHCP ACK - Transaction ID 0x2fa3c7f1
518	21.252232000	155.246.169.219	155.246.151.135	DHCP	342	DHCP Release - Transaction ID 0xadff03f5
636	27.951945000	0.0.0.0	255.255.255.255	DHCP	342	DHCP Discover - Transaction ID 0x403a45c2
637	27.960301000	155.246.151.135	255.255.255.255	DHCP	354	DHCP Offer - Transaction ID 0x403a45c2
638	27.960749000	0.0.0.0	255.255.255.255	DHCP	353	DHCP Request - Transaction ID 0x403a45c2
639	27.968916000	155.246.151.135	255.255.255.255	DHCP	354	DHCP ACK - Transaction ID 0x403a45c2

Frame 44: 342 bytes on wire (2736 bits), 342 bytes captured (2736 bits) on interface 0  
 Ethernet II, Src: HonHaiPr\_8e:42:90 (00:26:5e:8e:42:90), Dst: Cisco\_e5:87:00 (a4:4c:11:e5:87:00)  
 Internet Protocol Version 4, Src: 155.246.169.219 (155.246.169.219), Dst: 155.246.151.135 (155.246.151.135)  
 User Datagram Protocol, Src Port: bootpc (68), Dst Port: bootps (67)  
 Bootstrap Protocol

0000 a4 4c 11 e5 87 00 00 26 5e 8e 42 90 08 00 45 00 .L.....& ^B...E.  
 0010 01 48 47 b8 00 00 80 11 78 9d 9b f6 a9 db 9b f6 .HG..... X.....  
 0020 97 87 00 44 00 43 01 34 0b 1c 01 01 06 00 65 fb ...D.C.4 .....e.  
 0030 07 ac 00 00 00 00 9b f6 a9 db 00 00 00 00 00 00 ..  
 0040 00 00 00 00 00 00 00 26 5e 8e 42 90 00 00 00 00 .....& ^B....  
 0050 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 ..  
 0060 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 ..  
 0070 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 ..

- We see from this Figure that the first “ipconfig/release” command caused four DHCP packets to be generated: a DHCP Discover packet, a DHCP Offer packet, a DHCP Request packet, and a DHCP ACK packet.

